





## **“Thumb Scanner not Scanning” -Checking Bluetooth Connection**




1) Start on the main screen on the tablet & click Apps

2) On the Apps screen, click on settings

3) Click Connections and then click Bluetooth


4) Under Bluetooth Connections, make sure your wireless scanner is paired.




5) Pick up your Wireless Scanner and click the blue button turning it on.

•If it does not auto connect, click on Wireless Scanner under Bluetooth connections

•If it states “Connected as input device” under the Wireless Scanner Label, you have done the process correctly.



**Continued on Reverse Side...**



## BEEPER INDICATION KEY:

BEEP TYPE	BEEP MEANING:
Single Long Beep	Power up
Single Beep	Good read
Single Short Beep	The scanner reads a Code 39 of ASCII in configuration procedure.
Two Beeps	Wireless Connection
Two Short Beeps	The Scanner successfully reads a configuration barcode.
Five Beeps	Low Power
Three Beeps	Wireless disconnection: The scanner reads barcodes while disconnected.
Three Short Beeps	The scanner reads an unexpected barcode during configuration procedure (scan [RESET] to abort and start over).
Eight Short Beeps	The scanner switches from one communication mode to another.

## LED INDICATION KEY:

LED TYPE	LED MEANING:
Off	Standby or Power Off
Flashing Green	Disconnected or Discoverable
Green for 2 Sec	Good Read
Flashing Red	Low Power
Solid Red	Charging